

Ford Ranger Raptor PX3 XLT 2018-on 2.0L Bi Turbo EcoBlue

OS-FM-36



Installation guide for the Western Filters / Fuel Manager Vehicle Specific Pre-Filter Bracket Kit (requires drilling 2x 9mm holes).

Notes: ** Ensure ENGINE is OFF and is COOL to touch ! **

:: Reposition OEM Hoses beneath kit.

:: Slide filter housing as far as possible to passenger guard (img.4).

1. Identify installation area. Using the supplied bracket as a guide, mark & drill two holes through the existing OEM bracket to fix WF bracket. Note circular imprint on bracket.
2. Mount bracket to OEM bracket.
3. Configure Head Assembly with proper fittings using supplied sealant. Allow 5mins to dry.
4. Mount unit to bracket.
5. Disconnect the Factory Feed Line (FFL)
6. Using the supplied Kit Short Hose, connect one end to FFL and the other to the Pre Filter's Inlet (closest to mounting head).
7. Connect Longer Hose from Pre Filter Outlet to Factory Filter Inlet.
8. Turn ignition ON / OFF without starting the car (several times), to prime the fuel filter before starting the engine.

