

Ford Ranger, Everest (2017-on) Mazda BT50 (2015-18) 3.2L 2.2L

OS-20-23FM



Use this Install Guide to mount the Western Filters Vehicle Specific Fuel Manager Pre Filter Bracket Kit.

**\*\* Ensure ENGINE is OFF and is COOL to touch ! \*\***

**STEP 1:** Locate the Install Area - passenger's / left side of the engine bay.

**STEP 2:** Identify the OEM nuts and fit the Kit Bracket using them. Remove nuts, place bracket in place, secure with fittings and tighten.

**\*\* DO NOT REMOVE EXISTING Air/Con NUT ! \*\***

**STEP 3:** Place Thread Sealant on Brass Fitting Threads, then fit into the Head Assembly as shown (Out / In). Allow 5mins to dry.

**STEP 4:** Pre-fill the Fuel Manager (FM) with clean diesel before fitting to the Kit Bracket.

**STEP 5:** Disconnect the Supply Fuel Line from the Factory Filter.

**STEP 6:** Connect the Supply Fuel Line to the FM Inlet.

**STEP 7:** Attach the Kit Hose from the FM Outlet to the Factory Filter. Use the supplied clamps. Tighten all other joins

**STEP 8:** An alternative Donaldson Pre-Filter could be used on this bracket.

