

Ford Ranger 2011-15 Everest 2017-22 Mazda BT50 2015-20 3.2L 2.2L

OS-20-23FM



Use this Install Guide to mount the Western Filters Vehicle Specific Fuel Manager Pre Filter Bracket Kit.

**** Ensure ENGINE is OFF and is COOL to touch ! ****

STEP 1: Locate the Install Area - passenger's / left side of the engine bay.

STEP 2 & 3: Identify the OEM nuts and fit the Kit Bracket using them. Remove nuts, place bracket in place, secure with fittings and tighten.

**** DO NOT REMOVE EXISTING Air/Con NUT ! ****

STEP 4: Place thread sealant on the threads of the Brass and Aluminum fittings, then fit into the Head Assembly as shown (4. Out / In). Allow 5mins to dry.

STEP 5: Pre-fill the Fuel Manager (FM) with clean diesel before fitting to the Kit Bracket.

STEP 6: Disconnect the Supply Fuel Line from the Factory Filter.

STEP 7: Connect the Supply Fuel Line to the FM Inlet.

STEP 8: Attach the Kit Hose from the FM Outlet to the Factory Filter. Use the supplied clamps. Tighten all other joins

