

Ford Ranger, Everest (2017-on) Mazda BT50 (2015-18) 3.2L 2.2L

OS-20-23FS



Use this Install Guide to mount the Western Filters Vehicle Specific Fuel Manager Pre Filter Bracket Kit.

**** Ensure ENGINE is OFF and is COOL to touch ! ****

STEP 1: Locate the Install Area - passenger's / left side of the engine bay.

STEP 2: Identify the OEM nuts and fit the Kit Bracket using them.
Remove nuts, place bracket inplace, secure with fittings and tighten.

**** DO NOT REMOVE EXISTING Air/Con NUT ! ****

STEP 3: Place Thread Sealant on Brass Fitting Threads, then fit into the Head Assembly as shown (Out / In). Allow 5mins to dry.

STEP 4: Pre-fill the filter Element with clean diesel before fitting to the Kit Bracket.

STEP 5: Disconnect the Supply Fuel Line from the Factory Filter.

STEP 6: Connect the Supply Fuel Line to the Head Assy Inlet.

STEP 7: Attach the Kit Hose from the Head Assy Outlet to the Factory Filter.
Use the supplied clamps. Tighten all other joins

STEP 8: An alternative Fuel Manager Pre-Filter could be used on this bracket-

STEP 8: An alternative Fuel Manager Pre-Filter could be used on this bracket.

