

Ford Ranger / Ford Everest 3.2L PX1 PX2 PX3 TD 2012-18

OS-15-FM



Use this Install Guide to mount the Western Filters Vehicle Specific Fuel Manager Pre Filter Bracket Kit.

Notes: ** Ensure ENGINE is OFF and is COOL to touch ! **

1. Identify installation area (img1.)
2. Mount bracket to engine bay base (img.2)
3. Configure Head Assembly with proper fittings using supplied sealant. Allow 5mins to dry (img.3).
4. Mount unit to bracket (img.4)
5. Remove the Fuel Feed Line (FFL) from between Fuel Filter & Tank (img.5)
6. Connect the Hose with Straight-End to the Pre Filter Inlet & Tank (img.6)
7. Connect the Hose with Two 90° Ends, to the FM Pre Filter's Outlet, and the other end to the Factory Fuel Inlet (img.7)
8. Turn ignition ON / OFF without starting the car - several times, to prime the fuel filter and then start the engine.

