

Nissan Navara 2.3L ST NP300 2015-2021 YD23 DOHC Di 16V

OS-17-FM-2mic



Use this Install Guide to mount the Western Filters Vehicle Specific Fuel Manager Pre Filter Bracket Kit.

**Notes: \*\* Ensure ENGINE is OFF and is COOL to touch ! \*\***

**STEP 1:** Locate the Install Area - passenger's / left side of the engine bay.

**STEP 2:** Identify the OEM nuts and fit the Kit Bracket using them. Remove nuts, place bracket & struts inplace, secure with fittings and tighten.

**STEP 3:** Place Thread Sealant on Brass Fitting Threads, then fit into the Head Assembly as shown (Out / In). Allow 5mins to dry.

**STEP 4:** Pre-fill the Fuel Manager (FM) with clean diesel before fitting to the Kit Bracket.

**STEP 5:** Disconnect the Filter Fuel Line from the Factory Filter.

**STEP 6:** Connect the Filter Fuel Line to the FM Outlet.

**STEP 7:** Attach the Supplied Hose from the Factory Outlet to the FM Inlet. Use the supplied clamps. Tighten all other joins.

**STEP 8:** An alternative Fuel Manager Pre-Filter could be used on this bracket.

