

Nissan Navara 2.3L ST NP300 2015-on YD23 DOHC Di 16V

OS-17-FMB



Use this Install Guide to mount the Western Filters Vehicle Specific Fuel Manager Pre Filter Bracket Kit.

NOTE: ** Ensure ENGINE is OFF and is COOL to touch ! **

STEP 1: Locate the Install Area - passenger's / left side of the engine bay.

STEP 2: Identify the OEM nuts and fit the Kit Bracket using them. Remove nuts, place bracket & struts inplace, secure with fittings and tighten.

STEP 3: Place Thread Sealant on Brass Fitting Threads, then fit into the Head Assembly as shown (Out / In). Allow 5mins to dry.

STEP 4: Pre-fill the Fuel Manager (FM) before fitting to Kit Bracket. Unscrew the top, remove the white funnel and fill with clean diesel. Check that the rubber washer (gold) is in place, then return funnel and screw on top.

STEP 5: Disconnect the Supply Fuel Line from the Factory Filter.

STEP 6: Connect the Supply Fuel Line to the FM Inlet.

STEP 7: Attach the Supplied Hose from the FM Outlet to the Factory Filter. Use the supplied clamps. Tighten all other joints

STEP 8: An alternative Donaldson Pre-Filter could be used on this bracket.

