

Nissan Navara 2.3L ST NP300 2015-on YD23 DOHC Di 16V

OS-17-FSB



Use this Install Guide to mount the Western Filters Vehicle Specific Fuel Manager Pre Filter Bracket Kit.

Notes: ** Ensure ENGINE is OFF and is COOL to touch ! **

STEP 1: Locate the Install Area - passenger's / left side of the engine bay.

STEP 2: Identify the OEM nuts and fit the Kit Bracket using them. Remove nuts, place bracket & struts inplace, secure with fittings and tighten.

STEP 3: Place Thread Sealant on Brass Fitting Threads, then fit into the Head Assembly as shown (Out / In). Allow 5mins to dry.

STEP 4: Pre-fill the Fuel Separator (FS) with clean diesel before fitting to the Kit Bracket.

STEP 5: Disconnect the Supply Fuel Line from the Factory Filter.

STEP 6: Connect the Supply Fuel Line to the FS Inlet.

STEP 7: Attach the Supplied Hose from the FS Outlet to the Factory Filter. Use the supplied clamps. Tighten all other joints

STEP 8: An alternative Fuel Manager Pre-Filter could be used on this bracket.

