

Toyota Landcruiser 200 Series(2008-on) 4.5L TD VDJ200

OS-FM-21



Use this Install Guide to mount the Western Filters Vehicle Specific Fuel Manager Pre Filter Bracket Kit.



Notes: ** Ensure ENGINE is OFF and is COOL to touch ! **

1. Identify installation area (bracket leg fixing point).
2. Add fittings to Filter Assembly using supplied sealant - allow 5 minutes to dry.
3. Mount Bracket to Factory Fuel Filter mounting
- add supplied 6mm bolt to support leg.
4. Pre-fill Fuel Manager unit with clean diesel & mount unit to bracket
5. Disconnect the Factory Feed Line (FFL) from the tank
6. Re-connect FFL to the Pre-Filter's Inlet
7. Using the supplied Kit Hose (trim to desired length)
- connect one end to Factory Fuel Filter's Inlet
- connect other end to Pre-Filter's Outlet
- use the supplied Cable Ties to clutch hoses together.
8. Prime system using factory pump until hard to push.

