


2007-22 Toyota Landcruiser 70 Series 4.5L V8 TD VDJ76-79

OS-30-DON



Install Guide for Western Filters Pre-Filter Bracket Kit.

CAUTION: ** Ensure the engine is OFF & COOL before installation ! **

- 1: Locate the Install Area:** Passenger's side. Secure Bracket Leg using supplied bolt.
- 2: Prepare the Filter Head:** Remove pre-installed plugs (gold), add sealant, return as displayed. Add crush washers to adaptors, add sealant, screw into filter head.
- 3: Head Assy Configuration:** Add Hose End fittings into head adaptors.
- 4: Mount the Bracket:** Use the existing Factory Fittings within the engine bay.
- 5: Install the Pre-Filter:** Fit the filter head to Bracket. Pre-fill the Donaldson filter element with clean diesel. Screw filter element with bowl attached, into bracket mounted head.
- 6: Disconnect the Factory Fuel Line from Fuel Outlet:**
Remove the end of the Fuel Line connected to the Fuel Outlet (displayed in magenta).
- 7: Connect the Factory Fuel Line to the Pre-Filter:** (displayed in magenta).
- 8: Connect Kit Hose from Pre-Filter Outlet to Factory Filter:** (displayed in blue).
- 9: Priming the System:** Loosen Bleed nut and using the Primer on the factory filter prime the system until bubbles appear at the bleed nut and then re-tighten.

