

Toyota Landcruiser 70 Series (2007-on) 4.5L V8 TD VDJ76-79

OS-FM-30B



Installation Guide:

Use this guide to assist in the installation of the Western Filters, Vehicle Specific Bracket Kit to mount the Fuel Manager Pre Filter.

Notes: ** Ensure ENGINE is OFF and is COOL to touch ! **

1. Remove the 3x retaining bolts holding the Power Steering Reservoir, located on the Drivers side mudguard, behind the air box.
2. Slide the Kit Bracket beneath the reservoir, return bolts and tighten.
3. Fit the Kit Strut between the Bracket & Side of the eng.Bay then tighten.
4. Pre-fill the Fuel Manager (FM) with clean diesel.
Add the fittings using the supplied thread sealant - allow 5mins to dry.
5. Now fit the FM Unit to the Kit Bracket.
6. Remove the Supply Fuel Line from the Factory Filter.
7. Run Supply Fuel Line to the FM Inlet using supplied hose if needed.
8. Run the Fuel Line from the Factory Filter along the Firewall to FM Outlet.
9. Secure all Fuel Lines using ties and/or P-Clamps.
Prime the system using the hand primer on the OEM Filter.
When the primer goes firm, the engine is ready to start.

