

Toyota HiAce (2019-on) 2.8L Turbo Diesel GDH322R 1GD-FTV

OS-FM-40



Install Guide for the Western Filters Vehicle Specific
Fuel Manager Pre-Filter Bracket Kit OS-FM-40

Notes: ** Ensure ENGINE is OFF and is COOL to touch ! **

:: Reposition OEM Hoses beneath kit.

:: Slide filter housing as far as possible to passenger guard (img.4).

1. Identify installation area.
2. Mount bracket using the Factory.....
3. Configure Head Assembly with proper fittings using supplied sealant.
Allow 5mins to dry.
4. Mount unit to bracket.
5. Disconnect the Factory Feed Line (FFL)
6. Using the supplied Kit Short Hose, connect one end to FFL
and the other to the Pre Filter's Inlet (closest to mounting head).
7. Connect Longer Hose from Pre Filter Outlet to Factory Filter Inlet.
8. Turn ignition ON / OFF without starting the car (several times),
to prime the fuel filter before starting the engine.

