

2024-on Toyota Hilux 48 volt 2.8L 1GD-FTV

OS-54-DON



VIDEO SLIDE
INSTALLATION



Install Guide for Western Filters Pre-Filter Bracket Kit.

**** Ensure ENGINE is OFF and is COOL to touch ! ****

- 1:** The Kit Install Area is on the Passenger's left side. Use Factory Bolts and the Access Hole.
- 2:** Remove the Bolts holding the Fuse Box in place. Lift the Fuel Box up, while angling the Bracket in to the area. Slide the Bracket beneath the Fuel Box aligning the holes.
- 3:** From inside the wheel arch, pass the Kit Bolt through to secure the Bracket's Rear Leg. Return the Fuse Box Bolts and Tighten.
- 4:** Configure the Pre-Filter's Heady Assy with the flat plate against the bracket - facing the cabin. Remove the silver plugs from the left side of the assy and insert the supplied Black Adaptors (733-06-BLK). Fit the supplied Black 90° Fittings (401-06-BLK) on to each.
- 5:** Mount the Pre-Filter unit on the Kit Bracket and Secure.
- 6:** Disconnect the Factory Fuel Hose from the Fuel Outlet (magenta).
- 7:** Connect the Hose from the Factory Fuel Filter to the Pre-Filter Outlet (magenta).
- 8:** Connect the Supplied Kit Hose, to the Fuel Outlet and in to the Pre-Filter Inlet (green).
- 9:** Using a socket wrench 'Crack' to loosen the Top Bleed Nut and Prime using the pump on the Factory Fuel Filter until fuel bubbles appear, then re-tighten. All done ! Your Kit is now installed !



45-47 Forge St, Blacktown NSW 2148 | MON to FRI: 7:30am-5:00pm | SAT: 7:30am-12:00pm

Follow us on



westernfilters1

OS-54-DON