

T: (02) 9831 1715

STERN FILTER ERS, FILTER CLEANING &

www.westernfilters.net.au | enquiries@westernfilters.com.au



2024-on Toyota LC Prado 250 Series 48 Volt 2.8L TD MHEV 1GD-FTV

OS-56-DON





VIDEO WITH KITS INSTALLED


Install Guide for Western Filters Pre-Filter Bracket Kit. CAUTION: ** Ensure the engine is OFF & COOL before installation! **

- 1: Identify Install Area. Passenger's side.
- 2: Original Factory Filter Configuration
- 3: Unclip the Electrical Connector from the Factory Filter Head Assy
- 4: Remove Factory Filter Head Assy Fittings and lift off the OEM bracket bolt studs.
- 5: Remove the Silver Plug (coloured gold) from the right side of Pre-Filter Head Assy Add Crush Washers to the Silver Plugs, Sealant and insert into left side ports. Insert the supplied Black Adaptors (733-06-BLK), with Sealant into the right side of Assy. Fit the supplied Black 90° Fittings (403-06-BLK) into each Adaptor.
- **6:** Mount the Pre-Filter Unit on the Kit Bracket and secure.
- 7: Identify Factory Fuel Line
- 8: Remove the Factory Fuel Line











45-47 Forge St, Blacktown NSW 2148 | MON to FRI: 7:30am-5:00pm | SAT: 7:30am-12:00pm







T: (02) 9831 1715

WESTERN FILTER

FILTERS, FILTER CLEANING & MORE www.westernfilters.net.au | enquiries@westernfilters.com.au



2024-on Toyota LC Prado 250 Series 48 Volt 2.8L TD MHEV 1GD-FTV

OS-56-DON





VIDEO WITH KITS INSTALLED



- 10: Fuel Outlet to Pre-Filter: Fit one of the Kit hoses from the Fuel Line Outlet to the Pre-Filter INLET (Green). Add clamps to both the Pre-Filter INLET connection and where the hose connects to the Fuel Line Outlet.
- 11: Fit the other Kit Hose from the Pre-Filter OUTLET to the Factory Filter Inlet (Blue). Add clamps to both connecting hose ends.
- **12: NEW Configuration** of Factory Filter with Pre-Filter.
- 13a: 'Crack' (loosen ONLY) the Bleed Nut on the top-front of the Pre-Filter.
- 13b: Prime Fuel within Factory Filter: Use the Priming Pump until fuel 'bubbles' out of the Pre-Filter bleed nut.
- 13c: Re-tighten the Pre-Filter Bleed Nut.
- **14:** Congratulations! Your Pre-Filter Kit is now Installed.







45-47 Forge St, Blacktown NSW 2148 | MON to FRI: 7:30am-5:00pm | SAT: 7:30am-12:00pm



