

Holden Colorado LTZ Trailblazer Z71 Duramax 2.8L Diesel 2017-on

OS-PROV-39



WARNING: Engine damage will occur if incorrectly connected. Please follow Installation Guide
For vehicles that have travelled over 80,000 kms we recommend an intake manifold clean !

MANN Provent 200 IV Oil Catch Can Kit Install Guide

CAUTION: ** Ensure the engine is OFF & COOL before installation ! **

STEP 1: Identify Install Area (driver's side). Remove engine cover.

STEP 2: Identify the Coolant Tank bracket

Before: remove the bolts from the Tank bracket struts

After: align the WF bracket and secure using supplied bolts.

STEP 3: Adjust Provent Inlets in to displayed position. Fit Drain Hose to the base of the Provent Unit - Tighten the hose clamp.

STEP 4: Fit the Provent Unit to the Bracket using the supplied fittings.



STEP 1:



STEP 2:



STEP 3:



STEP 4:

- STEP 5:** Feed the clear Drain Hose down the side of the engine bay (ensure hose comes out inside the wheel arch).
Cut the Drain Hose the desired length and fit the Drain Tap - Tighten hose clamp.
***** Ensure Drain Tap is CLOSED *****
- STEP 6:** Remove the Factory Hose that runs from the top Crankcase Outlet to the Air Inlet.
- STEP 7:** Connect the supplied Short Hose to Provent's Lower Outlet. Connect the other end to the Air Intake.
- Secure with supplied clamps.
- STEP 8:** Connect the supplied Long Hose to Provent's Top Inlet.
Connect the other end to the Crank Case Outlet (re-using the OEM Factory Clamp)
- Secure with supplied clamps.
- STEP 9:** Cable-tie the OEM Water Hose to the provent Hoses - along with any other loose hoses, to prevent rubbing.
Re-fit engine cover. Your done !

NOTE: If the Provent is touching or too close to the Coolant Tank - push away, slightly bending the CT bracket.

Watch Slide Presentation: [SCAN QR-CODE on page 1: Prov-39 Install Slide Presentation >](#)



STEP 5:



STEP 6:



STEP 7:



STEP 8:



STEP 9: