

KIA Sportage 2010-15 SL / Hyundai Tucson 2011-18 2.0L TD I4 CRDi

OS-PROV-41



**MANN Provent 200 IV Oil Catch Can Kit Install Guide**

**CAUTION: \*\* Ensure the engine is OFF & COOL before installation ! \*\***

- STEP 1:** Identify Install Area - drivers side of engine bay.
- STEP 2:** Before attaching Provent to bracket:
  - Swivel Provent Inlet in to Position
  - Attach Drain hose - to the base of the Provent
- STEP 3:** Identify Fixing Point - Re-Use the Factory OEM Fitting (bolt).
- STEP 4:** Fit Provent to Bracket, then bolt the Bracket in to place  
Feed Drain Hose Down - down thru the engine bay  
- Secure - with hose clamp and cable ties.



**STEP 1:**



**STEP 2:**



**STEP 3:**



**STEP 4:**

KIA Sportage 2010-15 SL / Hyundai Tucson 2011-18 2.0L TD I4 CRDi

OS-PROV-41

- STEP 5:** Remove Breather Pipe from between Crankcase and Air Intake
- STEP 6:** Attach the supplied Articulated Hose from the Provent Lower Outlet. Connect to Air Intake - secure with clamps
- STEP 7:** Attach the supplied Straight Hose from the Provent Top Inlet. Connect to Crankcase Outlet - secure with clamps
- STEP 8:** Cable tie hoses where necessary. Dust off. Job done !

To View the Install Slide Presentation: [SCAN QR-CODE](#) on page 1

STEP 5:

