

Nissan Navara D40 STX 2.5L TD YD25 (2006-15)

OS-PROV-02



**WARNING: Engine damage will occur if incorrectly connected. Please follow Installation Guide**  
For vehicles that have travelled over 80,000 kms we recommend an intake manifold clean !

## MANN Provent 200 IV Oil Catch Can Kit Install Guide

*TIP: Soften hose ends in hot soapy water to push over existing fittings.*

### NOTE: Check Factory Air Box

**WILL FIT (A):** vehicles with VIN number VSK...

**WON'T FIT (B):** models with the Alternative Air Box with a bottom bulge.

### To Fit Alternative Air Box (B):



- Release Nut • Push Air Filter Box backwards to allow more space (may require removing mounting saddle)
- Cable Tie Provent unit in place

**\*\*\* Ensure engine is OFF & COOL \*\*\***

**STEP 1:** Identify install area, remove plastic engine cover.

**STEP 2:** Install 'T' bracket - using the supplied 10mm bolt and washer, ensure the two welded nuts face the front of vehicle.

**STEP 3:** Remove OEM Breather Hose  
- from between Top of Crankcase and the Air Intake.



STEP 1:

STEP 2:

STEP 3:

Nissan Navara D40 STX 2.5L TD YD25 (2006-15)

OS-PROV-02

**STEP 4:** Hose removed from between Top of Crankcase and Air Intake.**STEP 5:** Fit Drain Hose to base of Provent Unit.

Feed Drain Hose down through engine bay - ensure Drain Tap is OFF !

**STEP 6:** Secure Provent to Kit Bracket using supplied fittings.**STEP 7:** Fit the longest hose 5/8" end to Crankcase Outlet. Tighten clamp.**STEP 8:** Run the hose under Air Conditioner Pipe, under Intercooler Hose, connect to the Provent Top Inlet.**STEP 9:** Fit remaining hose to the Provent Lower Outlet, the 90 degree hose end to the Air Intake fitting.**STEP 10:** Secure hoses where required with supplied cable ties.**STEP 11:** Kit installed**STEP 4:****STEP 5:****STEP 6:****STEP 7:****STEP 8:****STEP 9:****STEP 10:****STEP 11:**