

TOYOTA Prado 2009-15 3.0L Turbo Diesel D4D KDJ150

OS-PROV-07



## MANN Provent 200 IV Oil Catch Can Kit Install Guide

**\*\* Ensure ENGINE is OFF & COOL to touch ! \*\***

**STEP 1:** Identify the Install Area - Driver's side of engine bay.

**STEP 2:** Using the OEM Bolts, secure the Provent Bracket.

**STEP 3:** Rotate Provent Ports in to correct position.

Fit Drain Hose to base of Provent. Secure with hose clamp.

Feed Drain Hose down through engine bay

**\*\* Ensure Tap is in OFF position \*\***

**STEP 4:** Fit flanged end of Hoses to Provent. Secure with clamps.



**STEP 1:**



**STEP 2:**



**STEP 3:**




**STEP 4:**

TOYOTA Prado 2009-15 3.0L Turbo Diesel D4D KDJ150

OS-PROV-07

- STEP 5:** Locate the OEM Breather Pipe (driver's side of engine bay).
  - Disconnect Breather Pipe - Swivel Top rubber fitting 180°.
- STEP 6:** Bolt Provent to Bracket
  - Using supplied nuts & bolts - secure with hose clamps.
- STEP 7:** Provent Lower Outlet to Air Intake
  - Attach flanged end of hose to Provent's Lower Outlet.
  - Using the supplied 16mm Plastic Straight Joiner, connect the Lower Hose to OEM Breather Pipe's rubber fitting (Air Intake)
  - Secure with clamps
- STEP 8:** Provent Top Inlet to Crank Case
  - Attach flanged end of Straight Hose to Provent's Top Inlet
  - Attach other end to the Crank Case Outlet
  - Secure with supplied hose clamps.
- STEP 9:** Cable-tie hoses to avoid rubbing where necessary.
- STEP 10:** Replace the plastic engine cover. Job done !



View Install Slide Presentation: [SCAN QR-CODE \(page.1\) >](#)

**STEP 5:**



**STEP 6:**



**STEP 7:**



**STEP 8:**