

Provent Kit for TOYOTA Prado 2009-15 3.0L Turbo Diesel D4D KDJ150

KIT No: OS-PROV-07



Mann Provent 200 Catch Can Kit Install Guide

Notes: ** Ensure ENGINE is OFF and is COOL to touch ! **

STEP 1: Identify the Install Area - Driver's side of engine bay.

STEP 2: Using the OEM Bolts, secure the Provent Bracket.


STEP 3: Rotate Provent Ports in to correct position.

- Fit Drain Hose to Base of Provent
- Secure with hose clamp
- Feed Drain Hose down through engine bay


**** Ensure Tap is in OFF position ****

STEP 4: Fit Hoses to Provent

- Flanged end of hoses - secure with clamps.




STEP 1:



STEP 2:



STEP 3:



STEP 4:

Provent Kit for TOYOTA Prado 2009-15 3.0L Turbo Diesel D4D KDJ150

KIT No: OS-PROV-07

STEP 5: Locate the OEM Breather Pipe - Driver's side of engine block.
- Disconnect Breather Pipe - Swivel Top rubber fitting 180°.

STEP 6: Bolt Provent to Bracket
- Using supplied nuts & bolts - secure with hose clamps.


STEP 7: Provent Lower Outlet to Air Intake
- Attach flanged end of hose to Provent's Lower Outlet.
- Using the supplied 16mm Plastic Straight Joiner, connect the Lower Hose to OEM Breather Pipe's rubber fitting (Air Intake)
- Secure with clamps

STEP 8: Provent Top Inlet to Crank Case
- Attach flanged end of Straight Hose to Provent's Top Inlet
- Attach other end to the Crank Case Outlet
- Secure with supplied hose clamps.

STEP 9: Cable-tie hoses to avoid rubbing where necessary.

STEP 10: Replace the plastic engine cover. Job done !

View Install Slide Presentation:
[SCAN QR-CODE \(page.1\) >](#)



STEP 5:



STEP 6:



STEP 7:



STEP 8: